

REVJAMS

REV-BTS100





*Satellite* **BLUETOOTH**  
LED SPEAKER

USERS MANUAL

Thank you for choosing the RevJams Satellite  
Bluetooth Speaker!

Please take the time to read this manual carefully,  
even if you are already familiar with a similar product.

## PACKAGE CONTENTS




1x RevJams Satellite Bluetooth Speaker

1x Micro USB Cable

1X 3.5mm AUX Audio Cable

1x User Manual

## SPEAKER CONTROLS AND INDICATOR



1. Microphone
2. Power Button
3. TF/Micro SD Card Slot
4. Mode button / Reset to factory settings
5. Volume - / Previous Track
6. Multi-Function Button- Play/Pause/Answer Call
7. Volume + / Next Track

## **GETTING STARTED**

To use your RevJams Satellite Bluetooth Speaker, please follow these steps:

1. Charge your Bluetooth Speaker fully
2. Pair your Bluetooth Speaker to a Bluetooth-enabled device prior to use.

## **CHARGING YOUR BLUETOOTH SPEAKER**

Your RevJams Satellite Bluetooth Speaker comes with a built-in rechargeable battery and a Micro USB charging cable. Charge fully before use. The battery indicator will turn red when charging and turn off once charging is complete. Initial charging time is approximately 3-4 hours.

## **POWERING ON/OFF**

Turn the Power Button switch to the right to Power ON, a Blue LED light will turn on. Turn the Power button switch to the left to Power OFF, the Blue LED light will turn off.

## PAIRING YOUR BLUETOOTH SPEAKER

In order to use your RevJams Satellite Bluetooth Speaker with a Bluetooth-enabled device, you will first need to pair the two.

1. Begin with the Bluetooth Speaker **being powered off and fully charged.**
2. Place the Bluetooth Speaker and the Bluetooth enabled device where they are easily viewable and no more than 3ft. apart.
3. Power ON the speaker. The speaker will automatically enter Bluetooth Pairing mode once powered on. If it does not enter pairing mode automatically, press the Mode button to switch to the Bluetooth Mode. A voice prompt will indicate that you are in Bluetooth Mode.
4. Activate your mobile phone's Bluetooth pairing function and select "**RevJams Satellite**" from the list of devices shown.

*When successfully paired a chime will be heard through the speaker*

## **RANGE**

Be sure to keep the speaker within **30 feet (10 meters)** of the connected media device at all times for optimal performance.

## **MODE FUNCTIONS**

The Bluetooth speaker is equipped with a Mode button that allows you to switch in between modes – Press the M button to switch between modes

## **MODES SEQUENCE**

Bluetooth Mode → TF/Micro SD card → AUX Audio → FM Mode


## **TF/MICRO SD CARD SLOT**

Insert your TF/ Micro SD card into the designated slot and press the M button to select the appropriate mode to play media

## AUX AUDIO PORT

The speaker features an AUX audio port, simply connect the speaker with your non-Bluetooth mobile phone/MP3 player/PC/laptop with the 3.5mm AUX audio cable and press the Mode button to enter "Line In" audio mode.

## FM MODE

In order for the FM Mode to work , the **USB cable must be Connected to the Bluetooth Speaker during use**– When using the FM mode for the first time, long press the  to scan for available FM stations, and then use the "+" and "-" to scroll through the available FM radio stations. The speaker will automatically save all stations for future use. Please allow 1-2 minutes for the initial scan to be completed.







## RESET TO FACTORY SETTINGS

In Bluetooth Mode, long press the M button for 3 seconds to restore the speaker to factory settings.



## LED INDICATOR GUIDE

STATUS	INDICATOR
Power On	Blue light
Charging	Red light
Charging complete	Red light turns off
Bluetooth Pairing Mode	Blue light flashes for Pairing

## CALL MODE

Powering ON/OFF	Turn the Power Button switch to the right to Power ON. Switch to the left to Power OFF
Answering a Call	Short Press the  button once to accept the call, or answer the call normally via your mobile phone. Short Press  again to end the call and resume music
Rejecting a Call	Press and hold the  button for 2 seconds to reject the incoming call.
Ending a Call	Short Press the  button to end the call or end the call directly from your mobile phone.

## MUSIC MODE

Adjusting the Volume	Press and Hold the Volume + to increase volume or Volume – to decrease volume. You can also adjust the volume on your handset or device
Play/Pause Music	Once connected, Press the  button once to play music. Short Press  the button to pause music.
Previous Track	Short Press the "-" key to select the previous track.
Next Track	Short Press the "+" key to select the next track.
Disconnect Bluetooth Connection	Press the M to switch between modes

## **SPECIFICATIONS**

Bluetooth version 3.0

Bluetooth range: 30 ft.

Output Power 3W

Speaker Output frequency range: 150Hz-20KHz

Discharge Current: 5V/0.5A

Battery: Built-in lithium battery 400mAh 3.7V

Charging Current: 200mA

Product Size: 2.8 X 2.8 X 1.6 inches

Speaker Weight: 6 oz.

Music Play Time: Up to 2.5 hours

Talk Time: Up to 4.5 hours

Standby time: Up to 20 hours

## **CARE AND MAINTENANCE**

1. Please charge your new speaker for at least 3 hours before first use.
2. To prevent damage and risk of electrical shock, do not expose this device to dust, vibration, rain, water or liquids of any kind.
3. Do not place device in close proximity to open flames or extreme heat sources.
4. Always place your device on level, flat and stable surfaces.
5. Avoid placing items on top of the speaker.
6. Do not use excessive force when pressing buttons or handling your speaker.
7. To clean your speaker, use only a dry, soft cloth or minimally damp cloth without any corrosive solvent or cleaning agent.

## **SAFETY**

To prevent fires, shock or injury, please do not disassemble or replace any parts of this device. In the event that your device may be damaged or in need of repair, please contact a professional maintenance or qualified service center for assistance. We are not responsible for any personal injury or property damage caused by improper use of this product.

Please do not allow the use of this device by small children without proper adult supervision.

## **FCC COMPLIANT**

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1)

This device may not cause harmful interference, and (2)

This device must accept any interference received, including interference that may cause undesired operation.

## WARRANTY

At RevJams, we are dedicated to making the best quality product. To back this up, your RevJams Satellite Bluetooth Speaker is covered by a One (1) Year Limited Manufacturer's Warranty.

Details of the warranty are as follows: for a period of one (1) year from the date of retail purchase, RevJams warrants that this product is free of any defects in manufacturing, materials and workmanship. During the warranty period, we shall, at our sole discretion, repair or replace any defective parts within a reasonable period of time.

Please visit our website **[www.revjams.com](http://www.revjams.com)** for more details

Or Email us at: **[customerservice@revjams.com](mailto:customerservice@revjams.com)** for any questions or concerns about your product.

